



Springs for GVW wastegates

GVW-40 Part number		Pressure															
PSI		3,0	4,0	6,0	7,0	9,0	10,0	12,0	13,0	14,5	16,0	17,0	19,0	20,0	22,0	23,0	25,0
BAR		0,2	0,3	0,4	0,5	0,6	0,7	0,8	0,9	1,0	1,1	1,2	1,3	1,4	1,5	1,6	1,7

Red	898344-0001	√						√	√		√						√
Blue	898344-0002		√						√	√		√				√	√
Green	898344-0003			√				√	√				√				
White	898344-0004				√			√						√	√		√
Brown	898344-0005					√				√					√		
Purple	898344-0006										√	√	√	√		√	√

GVW-45/50 Part number		Pressure															
PSI		3,0	4,0	6,0	7,0	9,0	10,0	12,0	13,0	14,5	16,0	17,0	19,0	20,0	22,0	23,0	
BAR		0,2	0,3	0,4	0,5	0,6	0,7	0,8	0,9	1,0	1,1	1,2	1,3	1,4	1,5	1,6	

Blue	898344-0002	√				√	√		√	√	√					√	√
Green	898344-0003		√						√			√	√		√		
White	898344-0004			√		√		√	√	√				√		√	
Brown	898344-0005				√			√	√	√	√	√					
Purple	898344-0006												√	√	√	√	√
Black	898344-0008										√	√	√	√	√	√	√

GVW-60 Part number		Pressure															
PSI		3,0	4,0	6,0	7,0	9,0	10,0	12,0	13,0	14,5	16,0	17,0	19,0	20,0	22,0	23,0	
BAR		0,2	0,3	0,4	0,5	0,6	0,7	0,8	0,9	1,0	1,1	1,2	1,3	1,4	1,5	1,6	

Red	898344-0001							√	√					√			√
Blue	898344-0002	√							√						√		
Green	898344-0003		√							√						√	√
White	898344-0004				√			√				√	√	√	√	√	
Brown	898344-0005			√							√						
Purple	898344-0006					√		√	√	√	√	√	√	√	√	√	√

Update: 20/03/2024